



HI-PEARL FROST EYE SHADOW WITH MICROEASE 110S AND MICROSLIP 519

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
Phase A			
Sericite PHN	Mica	10.50	Presperse LLC
Microease 110S	Synthetic Wax	6.00	Micro Powders, Inc.
Spheron® P-1500	Silica	2.00	Presperse LLC
Microslip 519	PTFE	2.00	Micro Powders, Inc.
Prestige Bright Gold	Mica (&) Titanium Dioxide	39.00	Eckart
Ultramarine Blue 7104	Ultramarines	10.00	Warner Jenkinson
Cosmetic Green C61-1245	Chromium Oxide Green	9.00	Sun Chemical
Methylparaben, USP	Methylparaben	0.20	ISP
Propylparaben, USP	Propylparaben	0.20	ISP
Germall 115	Imidazolidinyl Urea	0.10	ISP
Phase B			
Permethyl® 102A	Isoeicosane	7.37	Presperse LLC
Permethyl® 104A	Polyisobutene	3.63	Presperse LLC
Phase C			
Pearl Supreme UVS	Bismuth Oxychloride	10.00	Presperse LLC

Procedure

1. Combine ingredients of Phase A and mix well using a ribbon type blender.
2. When Phase A mixture is well dispersed, spray in Phase B and continue blending until uniformly dispersed.
3. Check draw down. Put back the batch into ribbon type blender to ensure proper dispersion.
4. Add Phase C, blending well the entire batch until well dispersed.
Press at 2500 psi.