



## **MATTE POWDER FOUNDATION WITH MATTEWAX 511 AND MICROSLIP 519**

<b><u>Product Name</u></b>	<b><u>INCI Name</u></b>	<b><u>%W/W</u></b>	<b><u>Supplier</u></b>
<b>Phase A</b>			
Sericite PHN	Mica	84.99	Presperse LLC
SM-1000	Mica (&) Silica	5.00	Presperse LLC
SP-29 UVS	Bismuth Oxychloride/ Silica/Mica	1.00	Presperse LLC
<b>Mattewax 511</b>	Polypropylene	5.60	<b>Micro Powders, Inc.</b>
<b>Microslip 519</b>	PTFE	1.80	<b>Micro Powders, Inc.</b>
Yellow Iron Oxide 7055	Iron Oxide	0.25	Warner Jenkinson
Red Iron Oxide 7080	Iron Oxide	0.25	Warner Jenkinson
Brown Iron Oxide C33-5136	Iron Oxide	0.04	Sun Chemical
Black Iron Oxide 7133	Iron Oxide	0.02	Warner Jenkinson
Methylparaben, USP	Methylparaben	0.20	ISP
Propylparaben, USP	Propylparaben	0.10	ISP
Germall II	Diazolidinyl Urea	0.25	ISP-Sutton
<b>Phase B</b>			
Panthenol	Panthenol	0.50	N/A

### **Procedure**

1. Combine ingredients of Phase A in a ribbon type blender.
2. Pass through a micropulverizer until uniformly blended and mixed.
3. Add Phase B ingredient and blend well until evenly dispersed.