



MOISTURIZING BATH GEL WITH MICROBLUE

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
Phase A			
Deionized Water	Water	54.50	N/A
Zilgel® SM	Glycerin (&) Water (&) Sodium Polyacrylate	32.50	Presperse LLC
Butylene Glycol	Butylene Glycol	6.50	N/A
Zilgel® Oil	Glycerin (&) Water (&) Sodium Polyacrylate (&) PVM/MA Copolymer	5.00	Presperse LLC
Phase B			
Germaben II	Propylene Glycol (&) Diazolidinyl Urea (&) Methylparaben (&) Propylparaben	1.00	ISP
Phase C			
MicroBlue 5025 or MicroBlue 2525	Polyethylene (&) FD&C Blue # Aluminum Lake	10.50	Micro Powders, Inc. Micro Powders, Inc.

Procedure

1. Charge deionized water and start mixing under propeller mixer. Add the remaining ingredients in sequence slowly, as each ingredient is added into the batch. Mix very gently so as not to create air bubbles.
2. Add Phase B into Phase A. Mix well.
3. Add gently Phase C into Phases A&B mixture. Mix slowly and gently in circular motion with a paddle mixer. Mix until uniformly dispersed.
4. Fill appropriate containers.