



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

BODY LOTION WITH MICROPOLY 1160S			
INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Sucragel CF	Caprylic/Capric Triglycerides, Water, Glycerin, Sucrose Laurate	10.00	Kinetik Technologies
Phase B			
Cetyl Alcohol	Cetyl Alcohol	2.00	Protameen Chemicals Inc.
Lexemul T	Glyceryl Stearate SE	1.00	Inolex
Dermol 89	Ethylhexyl Isononanoate	6.00	ALZO
Protachem ISP	Isostearyl Palmitate	3.00	Protameen Chemicals Inc.
Dermol M-5	Caprylic/Capric Triglycerides	2.00	ALZO
Shea Butter	Butyrospermum Parkii (Shea Butter)	4.00	N/A
Dow Fluid Corning 345	Cyclomethicone	2.20	Dow Corning
Phase C			
Deionized Water	Water	56.50	N/A
Aristoflex AVC	Ammonium Acryoldimethyltaurate/VP Copolymer	0.20	Clariant
Phase D			
Intelimer 8600 Emulsion	Poly C8-22 Alkyl Acrylate /Methacrylic Acid Cross Polymer /Water/ Propyl Alcohol	2.00	Evonik Industries
Phase E			
Micropoly[®] 1160S	Polyethylene	3.00	Micro Powders, Inc.
Glycerin	Glycerin	2.00	N/A
Hydrolite 5	Pentylene Glycol	2.00	Symrise
Phase F			
Camellia Sinensis (Green Tea) Extract	Camellia Sinensis Leaf Extract, Glycerin	1.00	Bell Flavors & Fragrances Inc.
Malva Sylvestris (Blue Malva) Extract	Malva Sylvestris Flower Extract /Glycerin	1.00	Bell Flavors & Fragrances Inc.
Extrapone Silk GW	Water/ Glycerin, Hydrolyzed Silk / Lactic Acid	1.00	Symrise
Phase G			
Hydrolite 5	Pentylene Glycol	1.00	Symrise
Cucumber Mint Fragrance	Fragrance	0.10	Bell Flavors & Fragrances Inc.
Total		100%	

Procedure

1. In a main kettle, with mixing, heat Phase A to 70-75°C.
2. In a separate vessel, heat Phase B to 70-75°C. When both phases are at 70-75°C, add Phase B to Phase A very slowly under mixing. When Phase A-B is uniform, and the gel is formed, increase and maintain temperature of this phase at 75-80°C.
3. In separate vessel, swell the Aristoflex in the deionized water (Phase C) with high stirring and heat to 70- 75°.
4. When Phase C is completely swelled and at temperature, add Phase D and mix until uniform.
5. Pre-mix Phase E in a separate beaker.
6. Add pre-mixed Phase E to Phases C-D and mix until uniform. Maintain 70-75°C.
7. With mixing, add phases C-D-E to Phases A-B. Homogenize for 10 min.
8. Cool the batch to 35°C. Add Phases F & G, and mix until uniform. Adjust pH if necessary.

Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098
www.mpipersonalcare.com