



EYE SHADOW WITH MATTEBLACK 523			
INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Talc Micro-Ace P-2-030	Talc (&) Methicone	6.00	Presperse
Sericite PHN	Sericite	9.25	Presperse
MatteBlack 523	Polypropylene (&) Black 2	25.00	Micro Powders, Inc.
Potassium Sorbate	Potassium Sorbate	0.20	Lotioncrafter
Tetrasodium EDTA	Tetrasodium EDTA	0.05	Lotioncrafter
Microsilk® 419	Polyethylene (&) PTFE	10.50	Micro Powders, Inc.
Phase B			
Bismica Black	Bismuth Oxychloride (&) Mica (&) Iron Oxide	5.00	Presperse
Ecosoft® 608 XF	Polylactic Acid	3.00	Micro Powders, Inc.
Sericite SL-012	Mica (&) Methicone	5.00	Presperse
Phase C			
Ceraphyl 375	Isostearyl Neopentanoate	1.95	Ashland LLC
Ceraphyl 847	Octyldodecyl Stearoyl, Stearate	3.65	Ashland LLC
Arlacel 83V	Sorbitan Sesquioleate	0.11	Croda Inc.
BarGuard™ CP	Caprylyl Glycol, Phenoxyethanol, Hexylene Glycol	0.79	Hampford Research Inc.
	Total	100%	
Procedure			
<ol style="list-style-type: none"> 1. Combine Ingredients of Phase A (in the order listed) and pass through the micropulverizer twice. 2. Add Phase B materials to Phase A. Blend well until evenly dispersed. 3. Add Phase C materials to Phase A-B and blend well until evenly dispersed. 4. Pre-mix Phase D materials separately. 5. Add Phase D materials to Phase A-B-C and blend well until evenly dispersed. 			
Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098 www.mpipersonalcare.com			