



## EYE SHADOW WITH MICROEASE 114S

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
<b>Phase A</b>			
Sericite PHN	Mica	36.10	Presperse LLC
<b>Microease 114S</b>	Synthetic Wax	2.00	<b>Micro Powders, Inc.</b>
Rose Talc	Talc	40.00	Presperse LLC
Zinc Laurate Z-12	Zinc Laurate	2.00	Ikeda
Luxsil®	Calcium Aluminum Borosilicate	2.00	Presperse LLC
Pearl II	Bismuth Oxychloride	1.00	Presperse LLC
Black Iron Oxide 7133	Iron Oxide	9.00	Warner Jenkinson
Methylparaben, USP	Methylparaben	0.30	ISP
Germall 115	Imidazolidinyl Urea	0.10	ISP
<b>Phase B</b>			
Permethyl® 102A	Isoeicosane	3.00	Presperse LLC
PEG-4 Dilaurate	PEG-4 Dilaurate	4.00	N/A
Crill 6	Sorbitan Isostearate	0.50	Croda

### Procedure

1. Combine ingredients of Phase A.
2. Mix well using a ribbon type blender.
3. Pass through a micropulverizer until uniformly pulverized.
4. Pre-mix Phase B ingredients, then spray into Phase A.
5. Mix well again into uniformity.
6. Press at 1500 psi in an appropriate container.