



FOAMING BODY SCRUB WITH ECOSCRUB 50PC

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
Phase A			
Deionized Water	Water	51.20	N/A
Carbopol Ultrez 20	Carbomer	0.60	Lubrizol
Phase B			
Propylene Glycol	Propylene Glycol	3.50	N/A
Germaben II	Propylene Glycol, Diazolidinyl Urea, Methylparaben, Propylparaben	1.00	ISP
Phase C			
Protachem ES-2	Sodium Laureth Sulfate	21.00	Protameen Chemicals Inc.
Proteric CAB-LC	Cocamidopropyl Betaine	7.00	Protameen Chemicals Inc.
Protasorb L-20	Polysorbate 20	1.50	Protameen Chemicals Inc.
Protamide CME	Cocamide MEA	3.50	Protameen Chemicals Inc.
Phase D			
Deionized Water	Water	3.00	N/A
Disodium EDTA	Disodium EDTA	0.05	N/A
Phase E			
Triethanolamine 99%	Triethanolamine	0.65	N/A
Phase F			
EcoScrub™ 50PC	Polylactic Acid	7.00	Micro Powders, Inc.

Procedure

1. In a main kettle, sprinkle the Carbopol Ultrez 20 on the surface of warm Deionized Water. (Heat the water to approximately 40°C) Wait until the polymer has completely wet out.
2. Begin gentle mixing for 10 min.
3. In a separate vessel, combine Phase B materials.
4. Add Phase B to Phase A. Mix until homogeneous.
5. Add ingredients in Phase C (in individual order) to Phase AB with slow continuous mixing. (NOTE: Make sure each ingredient is completely dispersed before going to the next.)
6. Pre-mix Phase D in a separate vessel.
7. Add Phase D with slow continuous mixing until completely dispersed.
8. Add Phase E to the batch, adjusting to pH 6.0–6.5. Mix until uniform.
9. Slowly add Phase F and mix until uniform.