



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

HI-PEARL FROST EYE SHADOW WITH MICROEASE 110S AND MICROSIP 519

INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Sericite PHN	Mica	10.00	Presperse
Microease 110S	Synthetic Wax	6.00	Micro Powders, Inc.
Spheron® P-1500	Silica	2.00	Presperse
Microslip® 519	PTFE	2.00	Micro Powders, Inc.
Prestige Bright Gold	Mica (&) Titanium Dioxide	39.00	Eckart
Ultramarine Blue 7104	Ultramarines	10.00	Sensient Colors LLC
Cosmetic Green C61-1245	Chromium Oxide Green	9.00	Sun Chemical
BarGuard™ S	Caprylyl Glycol, Phenoxyethanol & Sorbic Acid	1.00	Hampford Research Inc.
Phase B			
Permethyl® 102A	Isoeicosane	7.37	Presperse
Permethyl® 104A	Polyisobutene	3.63	Presperse
Phase C			
Pearl Supreme UVS	Bismuth Oxychloride	10.00	Presperse
	Total	100%	

Procedure

1. Combine ingredients of Phase A and mix well using a ribbon type blender.
2. When Phase A mixture is well dispersed, spray in Phase B and continue blending until uniformly dispersed.
3. Check draw down. Put back the batch into ribbon type blender to ensure proper dispersion.
4. Add Phase C, blending well the entire batch until well dispersed.
5. Press at 2500 Psi.