



# MICRO POWDERS, INC.

Specialty Micronized Wax Additives

## MATTE POWDER FOUNDATION WITH MATTEWAX 511 AND MICROSLIP 519

INGREDIENT	INCI NAME	% W/W	SUPPLIER
<b>Phase A</b>			
Sericite PHN	Mica	84.54	Presperse
SM-1000	Mica (&) Silica	5.00	Presperse
SP-29 UVS	Bismuth Oxychloride/ Silica/Mica	1.00	Presperse
<b>Mattewax 511</b>	Polypropylene	5.60	<b>Micro Powders, Inc.</b>
<b>Microslip® 519</b>	PTFE	1.80	<b>Micro Powders, Inc.</b>
Yellow Iron Oxide 7055	Iron Oxide	0.25	Sensient Colors LLC
Red Iron Oxide 7080	Iron Oxide	0.25	Sensient Colors LLC
Brown Iron Oxide C33-5136	Iron Oxide	0.04	Sun Chemical
Black Iron Oxide 7133	Iron Oxide	0.02	Sensient Colors LLC
BarGuard™ CP	Caprylyl Glycol, Phenoxyethanol & Hexylene Glycol	1.00	Hampford Research Inc.
<b>Phase B</b>			
Panthenol	Panthenol	0.50	Lotioncrafter
	<b>Total</b>	<b>100%</b>	

### Procedure

1. Combine ingredients of Phase A in a ribbon type blender.
2. Pass through a micropulverizer until uniformly blended and mixed.
3. Add Phase B ingredient and blend well until evenly dispersed.