



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

OIL FREE PRESSED POWDER EYE SHADOW WITH MICROEASE 110S

| INGREDIENT | INCI NAME | % W/W | SUPPLIER |
|----------------------------|---|-------------|----------------------------|
| Phase A | | | |
| Sericite PHN | Mica | 78.40 | Presperse |
| Microease 110S | Synthetic Wax | 6.50 | Micro Powders, Inc. |
| Spheron® P-1500 | Silica | 0.50 | Presperse |
| Titanium Dioxide 3328 | Titanium Dioxide 3328 | 1.60 | Sensient Colors LLC |
| Red Iron Oxide 7080 | Iron Oxide | 4.80 | Sensient Colors LLC |
| Yellow Iron Oxide C33-7733 | Iron Oxide | 3.20 | Sun Chemical |
| Black Iron Oxide C33-7774 | Iron Oxide | 4.00 | Sun Chemical |
| BarGuard™ S | Caprylyl Glycol, Phenoxyethanol & Sorbic Acid | 1.00 | Hampford Research Inc. |
| | Total | 100% | |

Procedure

1. Combine all ingredients and blend well using ribbon type blender.
2. Mix until the batch is evenly dispersed.
3. Check for undispersed color pigments.
4. Repeat the process if needed until batch is completely dispersed.
5. Press at 2000 Psi.