



# MICRO POWDERS, INC.

Specialty Micronized Wax Additives

## OIL FREE PRESSED POWDER EYE SHADOW WITH MICROSILK 419

INGREDIENT	INCI NAME	% W/W	SUPPLIER
<b>Phase A</b>			
Talc Micro-Ace P-2	Talc	45.90	Presperse
Zinc Stearate	Zinc Stearate	5.00	N/A
Sericite PHN	Mica	10.00	Presperse
Ultramarine Blue 7104	Ultramarine Blue	1.00	Sensient Colors LLC
Cosmetic Green CGI-1245	Chromium Oxide Green	12.50	Sun Chemical
Black Iron Oxide 7133	Iron Oxide Black	0.50	Sensient Colors LLC
Yellow Iron Oxide 7055	Iron Oxide Yellow	1.00	Sensient Colors LLC
BarGuard™ S	Caprylyl Glycol, Phenoxyethanol & Sorbic Acid	1.00	Hampford Research Inc.
<b>Microsilks® 419</b>	Polyethylene (&) PTFE	20.00	<b>Micro Powders, Inc.</b>
<b>Phase B</b>			
Prestige Green	Mica & TiO <sub>2</sub> & Iron Oxide	10.00	Eckart
<b>Phase C</b>			
Xiameter PMX-200, 50CST	Dimethicone	2.50	Dow Corning
Vitamin E Acetate	Tocopherol Acetate	0.25	BASF
	<b>Total</b>	<b>100%</b>	

### Procedure

1. Combine Phase A ingredients in a suitable blender and mix until uniform.
2. Pulverize through a 0.20" herringbone screen.
3. Return Phase A to the blender and add phase B + C. Mix until uniform.
4. Pass the combined phases through a pulverizer equipped with 0.062" herringbone screen.
5. Press at 1500 Psi in an appropriate container.