



OIL FREE PRESSED POWDER EYE SHADOW WITH MICROEASE 110S

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
Phase A			
Sericite PHN	Mica	79.00	Presperse LLC
Microease 110S	Synthetic Wax	6.50	Micro Powders, Inc.
Spheron® P-1500	Silica	0.50	Presperse LLC
Titanium Dioxide 3328	Titanium Dioxide	1.60	Whittaker
Red Iron Oxide 7080	Iron Oxide	4.80	Warner Jenkinson
Yellow Iron Oxide C33-7733	Iron Oxide	3.20	Sun Chemical
Black Iron Oxide C33-7774	Iron Oxide	4.00	Sun Chemical
Methylparaben, USP	Methylparaben	0.20	ISP
Propylparaben, USP	Propylparaben	0.20	ISP

Procedure

1. Combine all ingredients and blend well using ribbon type blender.
2. Mix until the batch is evenly dispersed.
3. Check for undispersed color pigments.
4. Repeat the process if needed until batch is completely dispersed.
5. Press at 2000 psi.