



OIL FREE PRESSED POWDER EYE SHADOW WITH MICROSILK 419

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
Phase A			
Talc Micro-Ace P-2	Talc	29.65	Presperse LLC
Zinc Stearate	Zinc Stearate	5.00	N/A
Sericite PHN	Mica	10.00	Presperse LLC
Ultramarine Blue 7104	Ultramarine Blue	1.00	Warner Jenkinson
Cosmetic Green CGI-1245	Chromium Oxide Green	12.50	Sun Chemical
Black Iron Oxide 7133	Iron Oxide Black	0.50	Warner Jenkinson
Yellow Iron Oxide 7055	Iron Oxide Yellow	1.00	Warner Jenkinson
Methylparaben, USP	Methylparaben	0.30	ISP
BHT	BHT	0.05	N/A
Microsilks 419	Polyethylene (&) PTFE	30.00	Micro Powders, Inc.
Phase B			
Prestige Green	Mica & TiO ₂ & Iron Oxide	10.00	Eckart

Procedure

1. Combine Phase A ingredients in a suitable blender and mix until uniform.
2. Pulverize through a 0.20" herringbone screen.
3. Return Phase A to the blender and add phase B. Mix until uniform.
4. Pass the combined phases through a pulverizer equipped with 0.062" herringbone screen.
5. Press at 1500 psi in an appropriate container.