



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

WET AND DRY PRESSED POWDER WITH MICROPOLY 220L AND MICROSLIP 519

INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Talc Micro-Ace P-2-030	Talc (&) Methicone	46.00	Presperse
Sericite SL-012	Mica (&) Methicone	10.00	Presperse
Micropoly® 220L	Polyethylene	20.00	Micro Powders, Inc.
Microslip® 519	PTFE	10.00	Micro Powders, Inc.
Yellow Iron Oxide C7055	Iron Oxide	2.00	Sensient Colors LLC
Red Iron Oxide C 7080	Iron Oxide	4.00	Sensient Colors LLC
Brown Iron Oxide C 7133	Iron Oxide	1.00	Sensient Colors LLC
Titanium Dioxide 3328	Titanium Dioxide	4.00	Sensient Colors LLC
BarGuard™ S	Caprylyl Glycol, Phenoxyethanol & Sorbic Acid	1.00	Hampford Research Inc.
Phase B			
Xiameter PMX-200, 50CST	Dimethicone	2.00	Dow Corning
	Total	100%	

Procedure

1. Combine Phase A ingredients and mix using a ribbon type blender.
2. Pass through a micropulverizer until uniformly pulverized.
3. Check the pigments dispersion by making a drawdown. Repeat the process if more blending is needed.
4. Spray Phase B ingredient into Phase A.
5. Mix and Blend until the color is homogeneously dispersed.
6. Pressed at 1500 Psi. in an appropriate container.

Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098
www.mpipersonalcare.com