



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

PRESSED POWDER BLUSH WITH MICROSIP 519			
INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Rose Talc	Talc	61.00	Presperse
Sericite PHN	Mica	15.00	Presperse
Microslip[®] 519	PTFE	2.00	Micro Powders, Inc.
Pearl II	Bismuth Oxychloride	4.00	Presperse
Spheron [®] P-1500	Silica	0.50	Presperse
Red Iron Oxide 7080	Iron Oxide	4.00	Sensient Colors LLC
D&C Red No. 30 Lake	D&C Red No. 30 (&) Talc	2.00	DeWolf Chemicals LLC
Zinc Laurate Z-12	Zinc Laurate	4.00	Ikeda
BarGuard [™] S	Caprylyl Glycol, Phenoxyethanol & Sorbic Acid	1.00	Hampford Research Inc.
Phase B			
Permethyl [®] 102A	Isoeicosane	2.00	Presperse
Permethyl [®] 104A	Polyisobutene	2.00	Presperse
Crill 6	Sorbitan Isostearate	0.50	Croda
	Total	100%	
Procedure			
<ol style="list-style-type: none">1. Combine ingredients of Phase A.2. Mix well using a ribbon type blender.3. Pass through a micropulverizer until uniformly pulverized.4. Pre-mix Phase B ingredients, then spray into Phase A.5. Mix well until the color of the mixtures is uniformly blended.6. Press at 1500 Psi in an appropriate container.			
Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098 www.mpipersonalcare.com			