



PRESSED POWDER BLUSH WITH MICROEASE 110S

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
Phase A			
Sericite PHN	Mica	84.55	Presperse LLC
Microease 110S	Synthetic Wax	5.00	Micro Powders, Inc.
Luxsil®	Calcium Aluminum Borosilcate	2.00	Presperse LLC
Red Iron Oxide 7080	Iron Oxide	4.00	Warner Jenkinson
Titanium Dioxide 3328	Titanium Dioxide	2.00	Whittaker
D&C Red #27 Al Lake	D&C Red No. 27 Aluminum Lake	2.00	N/A
Methylparaben, USP	Methylparaben	0.20	ISP
Propylparaben, USP	Propylparaben	0.20	ISP
Germall 115	Imidazolidinyl Urea	0.05	ISP

Procedure

1. Combine all ingredients in the order listed, mixing well before each addition.
2. Pass through a micropulverizer until color is evenly dispersed.
3. Press at 2000 psi.