



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

SATIN EYE SHADOW WITH MICROSILK 419			
INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Talc Micro Ace P-2	Talc	24.74	Presperse
Ultramarine Blue	Ultramarine Blue	12.34	Sensient Colors LLC
Unipure Red LC381 Oxide	Iron Oxide	4.26	Sensient Colors LLC
Optiphen OD	Caprylyl Glycol	0.50	Ashland LLC
Potassium Sorbate	Potassium Sorbate	0.20	Protameen Chemicals Inc.
Phase B			
Zinc Stearate	Zinc Stearate	5.00	Sun Ace Kakoh Ltd.
Bismuth Oxychloride	Bismuth Oxychloride	1.20	N/A
Microsilks® 419	Polyethylene & PTFE	20.00	Micro Powders, Inc.
Sericite PHN	Sericite	8.73	Presperse
Phase C			
SynCrystal Fire-Red	Synthetic Fluorophlogopite (& Iron Oxide	6.36	Eckart
Flamenco Blue 620C	Mica (& Titanium Dioxide	6.30	BASF
Timica® Extra Bright 1500	Mica (& Titanium Dioxide	4.94	BASF
Flamenco Ultra Sparkle 4500	Mica (& Titanium Dioxide	1.68	BASF
Phase D			
Xiameter PMX-200, 50CST	Dimethicone	3.50	Dow Corning
Vitamin E Acetate	Tocopherol Acetate	0.25	BASF
	Total	100%	
Procedure			
<ol style="list-style-type: none">1. Combine Phase A ingredients in a suitable blender and mix until uniform.2. Pulverize through a 0.20" herringbone screen.3. Return Phase A to blender and add Phase B and D. Mix until uniform.4. Add Phase C materials to Phase A-B-D. Mix until uniform.5. Pass the combined phases through a pulverizer equipped with a 0.062" herringbone screen.			
Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098 www.mpipersonalcare.com			