



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

SOFT FROST EYE SHADOW WITH MICROEASE 114S AND MICROSLIP 519

INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Sericite GMS-4C	Mica	48.20	Presperse
Microease 114S	Synthetic Wax	5.00	Micro Powders, Inc.
Velvet Veil 310	Mica (&) Silica	3.00	Presperse
Sericite SLZ-012	Mica (&) Methicone	6.50	Presperse
Microslip® 519	PTFE	1.80	Micro Powders, Inc.
Yellow C7055	Iron Oxide	4.50	Sensient Colors LLC
Red C7080	Iron Oxide	2.80	Sensient Colors LLC
Black C7133	Iron Oxide	5.20	Sensient Colors LLC
BarGuard™ S	Caprylyl Glycol, Phenoxyethanol & Sorbic Acid	1.00	RML Inc.
Phase B			
PermethyI® 102A	Isoeicosane	2.00	Presperse
PermethyI® 104A	Polyisobutene	2.00	Presperse
Phase C			
Xiameter PMX-200, 50CST	Dimethicone	3.50	Dow Corning
Pearl I	Bismuth Oxychloride	18.00	Presperse
	Total	100%	

Procedure

1. Combine ingredients of Phase A and mix well using a ribbon type blender.
2. Micropulverize 2X through a 0.027" herringbone screen.
3. When uniformly dispersed, spray in Phase B and continue to blend until uniformly dispersed.
4. Micropulverize 2X through a 0.062" herringbone screen and place back into ribbon blender.
5. Add Phase C and blend until dispersed.
6. Press at 1500 Psi.

Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098
www.mpipersonalcare.com