



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

SPARKLING BRONZE EYE SHADOW WITH MICROSLIP 519 AND MICROEASE 110S			
INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Talc Micro-Ace P-2	Talc	43.15	Presperse
Sericite PHN	Mica	8.00	Presperse
Microease 110S	Synthetic Wax	5.60	Micro Powders, Inc.
Spheron® P-1500	Silica	3.00	Presperse
Sericite SL-012	Mica (&) Methicone	6.50	Presperse
Microslip® 519	PTFE	2.00	Micro Powders, Inc.
Pearl I	Bismuth Oxychloride	2.75	Presperse
BarGuard™ S	Caprylyl Glycol, Phenoxyethanol & Sorbic Acid	1.00	Hampford Research Inc.
Phase B			
VP1 Bronze Sparkle	Bronze Powder (&) Stearic Acid	18.00	Eckart
Phase C			
Permethyl® 102A	Isoeicosane	6.67	Presperse
Permethyl®104A	Polyisobutene	2.22	Presperse
Liposorb SQO	Sorbitan Sesquioleate	1.11	Lipo Chemicals
	Total	100%	
Procedure			
<ol style="list-style-type: none">1. Combine Phase A in a suitable blender and mix until uniform.2. Pulverize Phase A twice through a hammer-mill. Check for undispersed pigment.3. Return the batch to the blender and add Phase B into Phase A.4. When the batch is uniform, pulverize once through a hammer-mill.5. Return the batch to the blender and spray Phase C into the batch. Mix until uniform.6. Pass twice through a hammer-mill.7. Check for undispersed oil.8. Press at 1500 Psi.			
Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098 www.mpipersonalcare.com			