



SOFT FROST EYE SHADOW WITH MICROEASE 114S AND MICROSLIP 519

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
Phase A			
Sericite GMS-4C	Mica	48.55	Presperse LLC
Microease 114S	Synthetic Wax	5.00	Micro Powders, Inc.
Velvet Veil 310	Mica (&) Silica	3.00	Presperse LLC
Sericite SLZ-012	Mica (&) Methicone	6.50	Presperse LLC
Microslip 519	PTFE	1.80	Micro Powders, Inc.
Yellow C7055	Iron Oxide	4.50	Warner Jenkinson
Red C7080	Iron Oxide	2.80	Warner Jenkinson
Black C7133	Iron Oxide	5.20	Warner Jenkinson
Methylparaben	Methylparaben	0.30	N/A
Propylparaben	Propylparaben	0.10	N/A
Imidazolidinyl Urea	Imidazolidinyl Urea	0.25	N/A
Phase B			
Permethyl® 102A	Isoeicosane	2.00	Presperse LLC
Permethyl® 104A	Polyisobutene	2.00	Presperse LLC
Phase C			
Pearl I	Bismuth Oxychloride	18.00	Presperse LLC

Procedure

1. Combine ingredients of Phase A and mix well using a ribbon type blender.
2. Micropulverize 2X through a 0.027" herringbone screen.
3. When uniformly dispersed, spray in Phase B and continue to blend until uniformly dispersed.
4. Micropulverize 2X through a 0.062" herringbone screen and place back into ribbon blender.
5. Add Phase C and blend until dispersed.
6. Press at 1500 psi.