



HAND CREAM WITH MICROSLIP 519

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
Phase A			
Water	Water	71.20	N/A
Propylene Glycol	Propylene Glycol	4.00	N/A
Veegum HV	Magnesium Aluminum Silicate	0.50	Vanderbilt
Methylparaben, USP	Methylparaben	0.20	ISP
Phase B			
Polawax	Emulsifying Wax NF	9.00	Croda
Lipocol S	Stearyl Alcohol	1.00	Lipo Chemicals
Propylparaben, USP	Propylparaben	0.10	ISP
Liponate NEB	C12-15 Alkyl Benzoate	7.00	Lipo Chemicals
PEG 400 Distearate	PEG 400 Distearate	1.00	N/A
50% Microslip 519/	PTFE/C12-15 Alkyl Benzoate	6.00	Micro Powders, Inc./
Liponate NEB			Lipo Chemicals
Fragrance		qs	

Procedure

1. Stir constantly.
2. Heat Phase A to 70°C.
3. In separate container, heat Phase B to 75°C.
4. Add B to A. Begin cooling to room temperature.
5. At 50°C, add the fragrance.
6. QS to volume with cold water.
7. Homogenize and fill.