



**SPARKLING BRONZE EYE SHADOW WITH MICROSLIP 519 AND MICROEASE 110S**

<u>Product Name</u>	<u>INCI Name</u>	<u>%W/W</u>	<u>Supplier</u>
<b>Phase A</b>			
Talc Micro-Ace P-2	Talc	43.55	Presperse LLC
Sericite PHN	Mica	8.00	Presperse LLC
<b>Microease 110S</b>	Synthetic Wax	5.60	<b>Micro Powders, Inc.</b>
Spheron® P-1500	Silica	3.00	Presperse LLC
Sericite SL-012	Mica (&) Methicone	6.50	Presperse LLC
<b>Microslip 519</b>	PTFE	2.00	<b>Micro Powders, Inc.</b>
Pearl I	Bismuth Oxychloride	2.75	Presperse LLC
Methylparaben, USP	Methylparaben	0.20	ISP
Propylparaben, USP	Propylparaben	0.10	ISP
Germall 115	Imidazolidinyl Urea	0.30	ISP
<b>Phase B</b>			
VP1 Bronze Sparkle	Bronze Powder (& Stearic Acid	18.00	Eckart
<b>Phase C</b>			
Permethyl® 102A	Isoeicosane	6.67	Presperse LLC
Permethyl® 104A	Polyisobutene	2.22	Presperse LLC
Liposorb SQO	Sorbitan Sesquioleate	1.11	Lipo Chemicals

**Procedure**

1. Combine Phase A in a suitable blender and mix until uniform.
2. Pulverize Phase A twice through a hammer-mill. Check for undispersed pigment.
3. Return the batch to the blender and add Phase B into Phase A.
4. When the batch is uniform, pulverize once through a hammer-mill.
5. Return the batch to the blender and spray Phase C into the batch. Mix until uniform.
6. Pass twice through a hammer-mill.
7. Check for undispersed oil.
8. Press at 1500 psi.